



Parrot FLYPAD Joystick Replacement

This guide will demonstrate how to replace the joystick on the Parrot Flypad.

Written By: HUY NGUYEN



INTRODUCTION


This guide will walk you through steps to replace your joystick.



TOOLS:

- [T6 Torx Screwdriver](#) (1)
 - [Magnetic Project Mat](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Joystick




- ❗ Total of 6 Screws are located in the back of the controller.
 - Four 0.9mm T6 screws
 - Two 0.1mm T6 screws
- Flip the Flypad over.
- Remove the six screws using a T6 screwdriver.
- ❗ Use a Magnetic Mat to prevent loss of screws. Set aside.

Step 2




- Flip the Flypad over again and separate the front and back. Be sure to remove the foam adhesive that connects the front plate to the motherboard.
- ⚠ Be aware that the Buttons (L1,R1) may fall out. Remember to put them back in place during reassembly.
- Use Ph0 tool to remove the screws holding the motherboard in place.
- Gently remove the motherboard from the front plate.

Step 3



- Pop the joysticks out by pulling gently.

Step 4



- Unscrew and replace joystick caps for a more comfortable grip.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-25 01:13:00 AM.

